


5.4 Spare parts list

The following are parts commonly required due to damage or expendability. Their failure or absence is likely to affect safety or performance of this appliance. For a pictorial representation of the part see the respective position number on the exploded view pictures on page 57.

	Description	Product No.
1	Casing	78155
2	Bracket	38092
3	Grommet cover	78145
4	Fan	73639
5	Fan seal (set of 5 pc.)	73640s
6	Gas injector 2E	73210
7	Gas valve	73645
8	Venturi	73641
9	50mm seal	73574
10	Air silencer tube	73646
11	Gas/air supply valve	73756s
12	Syphon	75986
13	Service set GLE complete (also includes item 5, 11, 14, 16, 23, 24, 25, 27, 68 and 92)	7746900411
14	Burner seal (set of 2 pc.)	8718600197
15	–	–
16	Heat exchanger - Gas/air supply seal	73728
17	Backside heat exchanger	8718600023
18	Gasket heat exchanger	8718600021
19	Heat exchanger	73659
20	Frontside heat exchanger	6718600141
21	Sight glass	73662
22	Combustion divider	73670
23	Ignition unit	8718600054
24	Ionisation electrode	38320
25	Ionisation electrode seal (set of 2 pc.)	73666s
26	–	–
27	Bracket ionisation electrode and glow ignitor (2 pc.)	–
28	–	–
29	Concentric adapter	78120
30	100 mm Lipring	78121
31	60 mm seal (bottom flue gas pipe)	73563
32	Flue gas pipe	78122
33	60 mm seal (top flue gas pipe)	73736
34	Flue gas pipe seal	73579

	Description	Product No.
35	Flue gas thermostat (STL) (push in type)	87105062670
36	Condensate collector	73630
37	Condensate trap	7746900187
38	Connection return	73583
39	Gas pipe	8718600028
40	Connection supply	73672
41	Automatic airvent	38618
42	Spring heat exchanger	73582s
43	O-ring heat exchanger (set of 10 pc.)	73580s
44	Heat exchanger seal (set of 2 pc.)	73584s
45	Safety sensor	78154
46	Supply pipe	78130
46	Supply pipe	7746900068
47	Pump Uper 15-50	78142
48	Connection return pipe	78133
49	Return pipe	78132
50	Connection return combi	78165
51	Internal mechanism three-way valve	73685
52	Servomotor three-way valve	73686
53	Securing pin of the servomotor	73687
54	Discharge pipe of pressure relief valve	78134
55a	Pressure relief valve 3 bar	78198
55b	Key to Pressure relief valve 3 bar	78202
56	By-pass	78143
57	Expansion vessel pipe	78135
58	Expansion vessel	78163
59	Connection plate heat exchanger	78167
60	DHW flow regulator	78138
61	DHW flow sensor	78137
62	Connection supply combi	78166
63	Flow sensor	78136
64	Mounting button	7746900854
65	Plate heat exchanger	78144
66	O-ring (set of 10 pc.)	78158s

Exploded view Combi unit (Buderus 500-24C, 500-28C)



7215 3100-075.3TD